



SHOCKWAVE SIZING CHART

Haptic Jacket

Size	Fits Chest (inches)
XXS	34/35
XS	36/37
S	38/39
M	40/41
L	42/43
XL	44/45
XXL	46/47
XXXL	48/49



***please note that chest size corresponds to the circumference of the chest**

Haptic Lower



Size	Lower Waist (inches)
26	26/27
28	28/29
30	30/31
32	32/33
34	34/35
36	36/37
38	38/39
40	40/41
42	42/43
44	44/45
46	46/47
48	48/49



***please note that lower waist size corresponds to the circumference of the lower waist.**